

IN THE CLAIMS:

Claims 1-6 (Previously Withdrawn).

7. (Currently Amended) A method of filling solid pharmaceutical product packaging comprising the steps of:

112 automatically selectively dispensing one or more solid pharmaceutical products from a plurality of different drug sources into a common funnel and (effecting relative motion in at least two directions between the funnel and plurality of product package template cavities) to selectively locate the funnel over individual ones of the cavities in order to place one or more solid pharmaceutical products from the plurality of different drug sources into each of said plurality of template cavities; and

thereafter automatically transferring the solid pharmaceuticals located in the plurality of product package template cavities into corresponding cavities of the product package member.

8. (Previously Added) The method of claim 7, further comprising a step of, during said step of selectively dispensing the solid pharmaceutical products, simultaneously sealing another pharmaceutical product package that has been previously filled with a variety of solid pharmaceuticals.

9. (Previously Added) The method of claim 7, further comprising a step of printing information on a pharmaceutical product package.

10. (Previously Added) The method of claim 8, further comprising a step of printing information on a pharmaceutical product package.

11. (Previously Added) The method of claim 7, further comprising a step of at least substantially simultaneously dispensing first and second pharmaceuticals from first and second canisters into a single template cavity.

12. (Previously Added) The method of claim 8, further comprising a step of at least substantially simultaneously dispensing first and second pharmaceuticals from first and second canisters into a single template cavity.

13. (Previously Added) The method of claim 7, wherein the step of effecting relative motion comprises moving the product package template cavities beneath the funnel such that each of the desired template cavities is placed beneath the funnel.

---